COBRA-COMMAND



PIN ASSIGNMENT

COLOR	PARTS SIDE	PIN	SOLDER SIDE	COLOR
BLACK	GROUND	1/A	GROUND	BLACK
BLACK	GROUND	2/B	GROUND	BLACK
RED	+5V	3/C	+5V	RED
RED	+5V	4/D	+5V	RED
	(NOT USED)	5/E	(NOT USED)	
ORANGE	+12V	6/F	+12V	ORANGE
	POST	7/H	POST	
WHITE/BROWN	COIN COUNTER (1)	8/J	(2) COIN COUNTER	
	(NOT USED)	9/K	(NOT USED)	
GRAY/GREEN	SPEAKER (+)	10/L	(–) SPEAKER	BLACK
	(NOT USED)	11/M	(NOT USED)	
WHITE/RED	VIDEO RED	12/N	VIDEO GREEN	WHITE/GREEN
WHITE/BLUE	VIDEO BLUE	13/P	VIDEO SYNC	WHITE/YELLOW
BLACK	VIDEO GND	14/R	SERVICE SWITCH	
	TEST SWITCH	15/S	TILT SWITCH	
GRAY	COIN 1	16/T	COIN 2	
YELLOW/BROWN	START (1P)	17/U	(2P) START	YELLOW/GREEN
YELLOW/WHITE	UP (1P) Purple	18/V	(2P) UP	PINK/WHITE
YELLOW/BLACK	DOWN (1P) Blue	19/W	(2P) DOWN	PINK/BLACK
YELLOW/RED	LEFT (1P) Green	20/X	(2P) LEFT	PINK/RED
YELLOW/ORANGE	RIGHT (1P) Yellow	21/Y	(2P) RIGHT	PINK/ORANGE
YELLOW/BLUE	SHOOT (1P) ORANGE	22/Z	(2P) SHOOT	PINK/BLUE
YELLOW/GRAY	BOMB (1P) Red	23/a	(2P) BOMB	PINK/GRAY
	(NOT USED)	24/b	(NOT USED)	
	(NOT USED)	25/c	(NOT USED)	
	(NOT USED)	26/d	(NOT USED)	
	GROUND	27/e	GROUND	
BLACK	GROUND	28/f	GROUND	BLACK

OPTION SWITCH SETTINGS									DIP SW #1
OPTIONS		1	2	3	4	5	6	7	8
1 COIN 1 COIN 2 COINS 3 COINS	1 CREDIT 2 CREDITS 1 CREDIT 1 CREDIT	OFF ON OFF ON	OFF OFF ON ON			OFF OFF OFF OFF			
1 COIN 1 COIN 2 COINS 3 COINS	1 CREDIT 2 CREDITS 1 CREDIT 1 CREDIT			OFF ON OFF ON	OFF OFF ON ON	OFF OFF OFF OFF			
DEMO SOUND	ON OFF					OFF OFF	OFF ON		
SCREEN TYPE	NORMAL INVERTED					OFF OFF		OFF ON	
GAME TYPE	COCKTAIL UPRIGHT					OFF OFF			OFF ON
		COIN A		COIN B					

OPTION SWITCH SETTINGS									DIP SW #2
OPTIONS		1	2	3	4	5	6	7	8
# OF LIVES	3 4 5 99	OFF ON OFF ON	OFF OFF ON ON					OFF OFF OFF OFF	OFF OFF OFF OFF
GAME LEVEL	NORMAL EASY HARD VERY HARD			OFF ON OFF OFF	OFF OFF ON OFF			OFF OFF OFF OFF	OFF OFF OFF OFF
CONTINUE FEATURE	OFF ON					OFF ON		OFF OFF	OFF OFF
EXTRA LIVES	50,000/150,000 100,000/200,000						OFF ON	OFF OFF	OFF OFF